

**IMPORTANT**

1. Always include complete heater model and serial number so that any specification change can be considered for parts shipment. It can save time and expense.
2. Specifications are subject to change without notice.
3. We reserve the right to substitute functional replacements.
4. Order either by Kit or Component Part No.

**Replacement Parts**

**Form RZ-NA-P-X/XE/RX/RPV**

Obsoletes Form RGM 705 (Version A)

**APPLIES TO:** Replacement Parts for Models listed in the Index including Models with prefix "C", "H", and "HC"



Index Reference by Page No.	Indoor		Outdoor				Indoor	Outdoor
	Duct Furnace	Packaged Systems	Duct Furnaces		Packaged Systems (Models discontinued as of 1990)		Unit Heaters (Obsolete)	Evaporative Cooler (Obsolete)
	X	XE/XJ	RX	RPV	RXE/RXJ	RPBE/RPVE/RPVJ/REB/REBJ	UA/XA/ XB*	RAM
Model Series Designations (including Models with prefix "C", "H", or "HC")	X	XE/XJ	RX	RPV	RXE/RXJ	RPBE/RPVE/RPVJ/REB/REBJ	UA/XA/ XB*	RAM
Baffles (Heat Exchanger)	10	10	10	10	10	10	--	--
Blower	--	11	--	--	11	11	--	--
Burner Rack and Carryovers	8	8	8	8	8	8	8**	--
Cabinet Parts (Blower)	--	12	--	--	13	13	--	--
Cabinet Parts (Heater)	4	4	4	6	4	4, 6	--	28
Carryover Regulator	8	8	8	8	8	8	--	--
Condensate Drain Kit	27	27	27	27	--	--	--	--
Contactors	--	14	--	--	14	14	--	--
Damper and Damper Controls	--	20-21	--	--	20-21	20-21	--	--
Door Latch Kit	--	13	--	--	13	13	--	--
Downturn Plenum Cabinet	--	--	--	--	20	20	--	--
Drives	--	19	--	--	19	19	--	--
Electrical Components	22-25	22-25	22-25	22-25	22-25	22-25	--	28
Fan Blades	--	--	--	--	--	--	18	--
Fill & Drain Kits (Option CT)	--	--	--	--	--	--	--	28
Filters and Filter Racks	--	12	--	--	13	13	--	28
Firestat	--	23	--	--	23	23	--	--
Flue Restrictors	--	--	6	--	6	6	--	--
Freezestat	--	24	--	--	24	24	--	--
Heat Exchanger	10	10	10	10	10	10	--	--
Limit Controls & Shields	22	22	22	22	22	22	--	--
Manifolds	8	8	8	8	8	8	--	--
Motors (Blower or Fan)	--	14-16	--	--	16-18	16-18	18	--
Pilots	26	26	26	27	26	26-27	26	--
Pressure Switch (air proving)	--	--	24	24	24	24	--	--
Pressure Switch (combustion air)	--	--	--	7, 22	--	7, 22	--	--
Pressure Switch (dirty filter)	--	24	--	--	24	24	--	--
Pressure Switch (gas)	23	23	23	23	23	23	--	--
Relays	23-24	23-24	23-24	23-24	23-24	23-24	23-24	--
Remote Console (Option RC)	25	25	25	25	25	25	--	--
Serial Number Designation	2	2	2	2	2	2	2	--
Starters & Starter Heaters	--	14-16	--	--	16-18	16-18	--	--
Switch, Blocked Vent	22	22	--	--	--	--	--	--
Switches, Disconnect & Toggle	25	25	25	25	25	25	25	--
Tape for Curbs	--	--	27	27	27	27	--	--
Transformer	24	24	24	24	24	24	--	--
***Valves (Shutoff)	8	8	8	8	8	8	8	--
Venters	--	--	--	6	--	6	--	--
Vertical Vent Kit (Option CC3)	--	--	--	6	--	6	--	--
Weatherhood (Outside air hood)	--	--	--	--	20	20	--	--
Z-Baffles (Option ZZ)	--	--	4-5	--	4-5	--	--	--

\* Replacement parts for obsolete unit heaters are limited. Cabinet parts are not available. \*\* Not available for Model UA.

**REFERENCES:**

Replacement Parts and Service Forms, Form RZ-NA

P-PILOTS, Pilots

P-STATS, Thermostats and Accessories

P-GC, Gas Conversion

P-LTR-TUBES, Burner Rack Carryover and Lighter Tubes

P-RG/RP/RBL, Parts for Model Series RG and RP

P-FAN-LIMIT, Fan and Limit Controls

\*\*\*P-VALVES, Serial Nos., Gas Valves, Ignition Controllers, and Maxitrol Gas Controls

P-VENTER, Power Venter for Model Series X and XE

737, Parts for Model PAK

CP-X-CONV, Convert Model Series X and RX with G19 or T32 to G770

CP-RPV-CONV, Convert Model Series RPV with G29 to G770

CP-RPV-PS, Pressure Switch Kit for Model Series RPV

CP-X/SC-IGN, Convert Model Series X and RX with G60 to G770

CP-EEDU/RPV/XLB-IGN, Convert Model Series RPV with G60 to G770

Installation/Operation Forms for currently manufactured Models, Form RZ-NA

I-OUTDOOR-DUCT, Models RX and RPV

I-XE/RGB/RPB, Model XE

I-X, Model X

**Code 305 - Firestat, P/N 42782, Honeywell  
#L4029E1029, Manual Reset Opens at 200°F**

P/N 121041, Firestat  
Gasket (used with firstat  
when installed less cover

P/N 120021, Firestat  
Shield (used with  
discharge firestat only)



**Code 306 - Ignition  
Controller, P/N 97782,  
J/C G67BG-5**



**Code 307 - Ignition Controller,  
P/N 97547, J/C G770NGC-4**

Timing cycle 120 second lockout




**CODE 306 ABOVE**  
IF THE CONTROL IN THE UNIT LOOKS  
LIKE THIS YOU DO NOT NEED THE KIT  
AND CAN JUST REPLACE THE  
IGNITION CONTROL P/N: WB-31167



**CODE 307 ABOVE**  
IF THE CONTROL IN THE UNIT LOOKS LIKE  
THIS YOU DO NOT NEED THE KIT AND CAN  
JUST REPLACE THE IGNITION CONTROL  
P/N: WB-31168



**Code 310**  
**Bracket, P/N 104156** (used with Essex  
brand P/N 41700); **P/N 100260** (used with  
Honeywell brand P/N 41700 - see Code 309)  
**Gasket, P/N 7726**  
**Retaining Plate, P/N 7727**



**Code 311**

**Ductstat Sensor Holder,  
#TE6001-1, P/N 115850**



**Ductstat Sensor,  
#SET A99BC-25C,  
P/N 115851**

(Used in Options AG15-AG20  
with Code 312)

**Code 312 - Remote  
Electronic  
Ductstat**



**A = Ductstat Temperature Selector Module, J/C  
A350AA-1C, P/N 115848** (used in Options AG 15-20)

**B = Stage Adder Module, J/C S350AA-1C, P/N 115849**  
(used in Options AG 15-20)

**C = Digital Temperature Display Module, J/C D350AA-  
1C, P/N 115852** (used in Options AG 16, 18, and 20)

**Code 316 - Freezestat  
Relay, P/N 103317,  
Products Unlimited 9400-  
04Q180**



**Code 313 - Low Pressure Gas  
Switch (normally open switch)**



For natural gas  
units, P/N 93849,  
Autunes RLGP  
#803112701

For propane gas  
units, P/N 149176,  
Autunes RLGP  
#803112703




**Bracket,  
P/N 149397**

**Code 314 - High Gas  
Pressure Switch, Autunes  
HGP-AM1,  
P/N 93850 (normally closed  
switch)**



**Vent Limiter, Maxitrol  
A1209, P/N 123481**

**Code 315 - Time  
Delay Relay,  
P/N 46233,  
TI 60000GO-17**



**Code 317 - P/N 11606, Time  
Delay Relay, 30 second  
delay, 24 volt coil  
(Same as Option BH2)**



1 = N. C.  
2 = COM  
4 = N. O.  
H = Coil  
H = Coil