

REPLACEMENT PARTS: SEPARATED COMBUSTION FURNACES

SC SERIES MODELS: SC, SCE, SSCBL, AND SSCDBL




TABLE OF CONTENTS

REFERENCES	2
RATING AND IDENTIFICATION PLATES AND REPLACEMENT PARTS TAGS	3
SERIAL NUMBERS	5
ELECTRICAL COMPONENTS	6
VENTER AND FLUE DUCT COMPONENTS	16
INTERIOR CABINET AND HEAT EXCHANGER COMPONENTS	18
BURNER RACK COMPONENTS	19
PILOT COMPONENTS	22
SPECIAL MANIFOLD COMPONENTS	24
REPLACEMENT BLOWER MOTORS, STARTERS, AND VARIABLE FREQUENCY DRIVES FOR UNITS MANUFACTURED <i>BEFORE</i> APR 2013	26
REPLACEMENT BLOWER MOTORS, STARTERS, AND VARIABLE FREQUENCY DRIVES FOR UNITS MANUFACTURED <i>AFTER</i> MAR 2013	32
DRIVE COMPONENTS	36
CABINET COMPONENTS	45
FILTER ARRANGEMENTS	54
DAMPER COMPONENTS	56
VENT TERMINAL/COMBUSTION AIR INTAKE COMPONENTS	59

IMPORTANT

1. Always include complete model and serial number so that any specification change can be considered for parts replacement. It can save time and expense.
2. In keeping with our policy of continuous product improvement, we reserve the right to alter any information shown here. Specifications are subject to change without notice.
3. We reserve the right to substitute functional replacements.
4. Order by Part Number (PN) not by option designation.

CABINET COMPONENTS—CONTINUED

Table 38. Blower Section Cabinet Components (Model SCE)										
Item No.	Cabinet Applicability	Component	Description	Unit Size						
				125	150, 175	200, 225	250, 300	350	400	
				PN (Quantity)*						
1	Standard	Cabinet** (not shown)	Shipped knocked down (assembly required)	12545	12546	12547	12548	12549	12550	
	Optional			84215	84216	84217	84218	84219	84220	
2	Standard	Door	Without insulation	51041 (2)			51042 (2)			
	Optional		With insulation	84221 (2)						
3	Standard	Panel, top/bottom	Without insulation	11522 (2)	11529 (2)	11197 (2)	11564 (2)	11574 (2)	11583 (2)	
4	Optional	Panel, top	With insulation	11825	11842	11767	11856	11862	11777	
5	Standard	Support	Corner	11518			11211			
6	Standard or optional			11519			19982			
7	Standard			11517 (2)			11210 (2)			
	Optional			11517			11210			
8	Standard or optional			Hanger	10219 (2)					
9	Standard or optional	Hanger	Assembly	9557 (2)						
10	Optional	Angle	Duct connecting	11523 (2)	11530 (2)	11536 (2)	11567 (2)	11576 (2)	11584 (2)	
11	Standard or optional	Plug	1/2-inch	82413 (2)						
12	Optional	Panel, end	Without insulation	12075	12411	11540	12414	12029	11589	
13		Insulation	End panel	11158	11165	11167	11176	11180	11184	
14		Panel, bottom	Left side	11203						
15		Panel, bottom	Right side	11204						
16		Panel, rear	Bottom section	11526	11533	11392	11571	11580	11393	
17		Cap	Inlet	12513	12514	11538	12515	12516	11587	
18		Insulation (not shown)	Bottom	11155	11162	11167	11176	11180	11184	
19		Standard or optional	Filter rack** (not shown)	Without filters	24501	24503	24505	24507	24509	24511
19A	Support		Filter	19704 (2)	19710 (2)	19717 (2)	19723 (2)	19729 (2)	19736 (2)	
20	Filter support assembly		Intermediate	19708	19715	19721	19727	19734	19742	
21	Stop		Filter	—				19733	19740	
22	Filter, replacement (not shown)		2-inch, optional	Refer to Table 40						
23	Filter, replacement (not shown)		1-inch, optional	Field-supplied						
24	Optional		Inlet screen (not shown)	Without dampers (same as option AZ3)	109134	109135	109136	109137	109138	109139
		With dampers (same as option AZ4)		109146	109147	109148	109149	109150	109151	
		Screen (not shown)	For horizontal and bottom openings, with dampers (same as option AZ5)	109152	109153	109154	109155	109156	109157	
25	—	Blower back (not shown)	Assembly	193986	194054	194093	193988	194063	194064	
26		Mounting bracket	Blower motor, for <1-HP motor	44409	44410		44409	44410		
27		Bracket assembly	Motor adjustment	44411						
28		Mounting plate	Blower motor, for ≥1-HP motor	194117	12579		194117	12579		
29		Support, blower motor mounting plate	Left	12576						
30			Right	12577						
31		Rubber feet	With mounting hardware	64940						
32		Blower (not shown)	Complete with shaft and bearings	1357	—		—			
				—	36429		—			
33		Blower (not shown)	Right side, without shaft and bearings	—				36430	—	
34				36431	—		36432			
		34	Blower (not shown)	Left side, without shaft and bearings	—				36431	—
34		36433			—		36433			

*Quantity is one (1) unless otherwise indicated.

**The filter rack is optional and fits either a standard or an optional cabinet. Assembly is required.