

IMPORTANT

1. Always include complete heater model and serial number so that any specification change can be considered for parts shipment. It can save time and expense.
2. Specifications are subject to change without notice.
3. We reserve the right to substitute functional replacements.
4. Order by Part No.; not Heater Option Designation.

Replacement Parts

**Applies to: Model CAUA and
Cased Cooling Coil
Model ACU**

**Model CAUA Upflow
Furnace/Blower Unit
with Model ACU
Cooling Coil and
Optional Mixing Box**

**Index****B**

Bearings 12, 13
Belt 9, 10, 11
Blower 12
Blower Mount Assy 12, 13
Bottom Return Air Filter
Cabinet 21
Burner 16

C

Cabinet Parts 14
Capacitor 3, 4
Venter Motor Capacitor 15
Cooling Coil 22
Coils 23
Coils for Starter Overloads 8
Concentric Adapter 15
Condensate Drain Kit 17
Remote Consoles 5
Contactor 3, 4

D

Damper Controls 19
Damper Linkage 19
Damper Rod 19
Dampers 18
Discharge Plenum 24
Disconnect Switches 5
Door Interlock Switch 3, 4
Door Latch Kit 20

Belt Drives 9
Drive Table for TEFC
motors 10, 11
Ductstat 3, 4

E

Electrical Components 3, 4
Enthalpy Control 19
Evaporator Coi 23

F

Filter Cabinets 20
Filter Rack 18
Filters 18, 20, 21, 24
Flame Rollout Switch 3, 4
Flame Sensor 4

G

Gas Conversion Kits 17

H

Heat Exchanger 16, 17

I

Ignition Board 3, 4
Ignition Cable 3, 4
Inlet Base 24
Isolator 14

L

Red Light 5
Limit Control 3
Line Reactors (VFD) 6

Logic Module 19

M

Mixed Air Controller 19
Mixing Box 18
Belt-Driven Blower Motor 8
MOTOR 7, 8
Belt-Driven Blower Motor 7
Blower Motor, Direct Drive 3
Damper Motor 19
Motor Mounting Plate 12, 13

O

Burner Orifices 17
Outdoor Air Controller 19

P

Paint 14
Potentiometer 19
Pressure Switch 3, 4
Blower Pulley 9, 10, 11
Motor Pulley 9, 10, 11

R

Rating Plate 2
Reducers 23
Relay 3, 4

S

Enthalpy Sensor 19
Flame Sensor 3
Mixed Air Sensor 19

Serial No. 2
Blower Shaft 12, 13
Spark Electrode 3, 4
Starter 8
STARTER 8
Starter 7
Starter OVERLOAD 7, 8
Static Pressure Tap 17

T

Terminal Strip 3, 4
TEV Bulb Placement 23
Thermostat Cover 5
Thermostatic Expansion
Valve 22
Thermostatic Expansion
Valves 23
Thermostats 5
Transformer 3, 4
Tubing 3

V

Variable Frequency Drive
(VFD) 6
Vent/Combustion Air Kits 15
Vent Cap 15
Venter Housing 15
Venter Motor 15

Code	Description	Qty	150	200	250	300	350	400
134	Burner Box	Aluminized	1	193997	193998	193999		
		409SS	1	258985	258986	258987		
135	Drain Hole Seal	1	165741					
136	Manifold	1	151787	151788	160931	160932	160933	160934
137	Burner/Manifold Support	2	160437	160437	160928			
138	Burner Orifices (sea level)	>	8	10	13	15	12	14
		Natural Gas	164866	11833			11835	45870
			2.1MM	#44			#37	#38
		Propane	97359	11830	97359	11830	9789	61653
			1.25MM	#55	1.25MM	#55	#53	1.55MM
139	Burner Rack Assy (burners and support rack)	1	163104	163105	163106	163107	163108	163109
139A	Burner Support Rack	1	160625		160626		160627	
139B	Burner, Beckett	>	8	10	13	15	12	14
			164870, #RZ11					164869, #RZ10
140	Burner Box Air Baffle - Left (inside the burner box)	1	--	--	--	--	166317	
141	Burner Box Air Baffle - Right (inside the burner box)	1	--	--	--	--	166318	
142	Burner Box Gasket - Front Btm	2	162806		162807		162808	
143	Burner Box Gasket - Front Side	2	162800					169939
144	Burner Box Gasket - Top Side	2	162801					
145	Burner Box Gasket - Side	2	162809					169940
146	Burner Box Gasket - Btm Rear	2	161171		161172		161173	
*147	Burner Box Cover - Right Half Assy (including cover, gaskets, and viewport)	1	175280	175281	175282	175283	175284	175285
147A	Burner Box Cover Right Half Gasket - Top	1	162803					
147B	Burner Box Cover Right Half Gasket - Front	1	162804					
147C	Burner Box Cover Right Half Gasket - Right	1	162811		162812		162813	
*148	Burner Box Cover - Left Half (150-300 include collar)	1	194003	194004	194024	194025	160936	160937
149	Burner Box Cover Gasket - Left	1	162814		162815		162816	
150	Air Inlet Box (on top of the burner box, Sizes 350 & 400)	1	--	--	--	--	166315	
151	Air Inlet Box Gasket - Side	2	--	--	--	--	169937	
152	Air Inlet Box Gasket - Front	1	--	--	--	--	169936	
153	Air Inlet Cover with inlet air collar	1	--	--	--	--	166530	
154	Viewport Gasket (left side)	1	116037					
155	Viewport (left side)	1	115984					
156	Viewport Retainer (left side)	1	142711					
157	Static Pressure Tap, TDI #AA3743	2	116043					
158	Burner Front Cover	1	194124					
159	Burner Cover Gasket	1	194127					
160	Burner Condensate Drain Kit (for use with cooling coil)	1	165951					
161	Tube Clamp Support (See illustration on page 14.)	2	163435	163436	163437	163438	163439	163440
162	Gas Conversion Kits (application by Serial No. valve code)	Natural to Propane	269833	269834	170815	170816	170817	170818
		Propane to Natural	269849	269850	170810	170810	170811	170812
163	Replacement Heat Exchanger Assy - Aluminized Steel	1	169963	169964	169965	169966	169967	169968
	Replacement Heat Exchanger Assy - Stainless Steel	1	259384	259385	259386	259387	259388	259389