

IMPORTANT

1. Always include complete heater model and serial number so that any specification change can be considered for parts shipment. It can save time and expense.
2. Specifications are subject to change without notice.
3. We reserve the right to substitute functional replacements.
4. Order either by Kit or Component Part No.

Replacement Parts

Form RZ-NA-P-X/XE/RX/RPV

Obsoletes Form RGM 705 (Version A)

APPLIES TO: Replacement Parts for Models listed in the Index including Models with prefix "C", "H", and "HC"



Index Reference by Page No.	Indoor		Outdoor				Indoor	Outdoor
	Duct Furnace	Packaged Systems	Duct Furnaces		Packaged Systems (Models discontinued as of 1990)		Unit Heaters (Obsolete)	Evaporative Cooler (Obsolete)
	X	XE/XJ	RX	RPV	RXE/RXJ	RPBE/RPVE/ RPVJ/REB/REBJ	UA/XA/ XB*	RAM
Model Series Designations (including Models with prefix "C", "H", or "HC")	X	XE/XJ	RX	RPV	RXE/RXJ	RPBE/RPVE/ RPVJ/REB/REBJ	UA/XA/ XB*	RAM
Baffles (Heat Exchanger)	10	10	10	10	10	10	--	--
Blower	--	11	--	--	11	11	--	--
Burner Rack and Carryovers	8	8	8	8	8	8	8**	--
Cabinet Parts (Blower)	--	12	--	--	13	13	--	--
Cabinet Parts (Heater)	4	4	4	6	4	4, 6	--	28
Carryover Regulator	8	8	8	8	8	8	--	--
Condensate Drain Kit	27	27	27	27	--	--	--	--
Contactors	--	14	--	--	14	14	--	--
Damper and Damper Controls	--	20-21	--	--	20-21	20-21	--	--
Door Latch Kit	--	13	--	--	13	13	--	--
Downturn Plenum Cabinet	--	--	--	--	20	20	--	--
Drives	--	19	--	--	19	19	--	--
Electrical Components	22-25	22-25	22-25	22-25	22-25	22-25	--	28
Fan Blades	--	--	--	--	--	--	18	--
Fill & Drain Kits (Option CT)	--	--	--	--	--	--	--	28
Filters and Filter Racks	--	12	--	--	13	13	--	28
Firestat	--	23	--	--	23	23	--	--
Flue Restrictors	--	--	6	--	6	6	--	--
Freezestat	--	24	--	--	24	24	--	--
Heat Exchanger	10	10	10	10	10	10	--	--
Limit Controls & Shields	22	22	22	22	22	22	--	--
Manifolds	8	8	8	8	8	8	--	--
Motors (Blower or Fan)	--	14-16	--	--	16-18	16-18	18	--
Pilots	26	26	26	27	26	26-27	26	--
Pressure Switch (air proving)	--	--	24	24	24	24	--	--
Pressure Switch (combustion air)	--	--	--	7, 22	--	7, 22	--	--
Pressure Switch (dirty filter)	--	24	--	--	24	24	--	--
Pressure Switch (gas)	23	23	23	23	23	23	--	--
Relays	23-24	23-24	23-24	23-24	23-24	23-24	23-24	--
Remote Console (Option RC)	25	25	25	25	25	25	--	--
Serial Number Designation	2	2	2	2	2	2	2	--
Starters & Starter Heaters	--	14-16	--	--	16-18	16-18	--	--
Switch, Blocked Vent	22	22	--	--	--	--	--	--
Switches, Disconnect & Toggle	25	25	25	25	25	25	25	--
Tape for Curbs	--	--	27	27	27	27	--	--
Transformer	24	24	24	24	24	24	--	--
***Valves (Shutoff)	8	8	8	8	8	8	8	--
Venters	--	--	--	6	--	6	--	--
Vertical Vent Kit (Option CC3)	--	--	--	6	--	6	--	--
Weatherhood (Outside air hood)	--	--	--	--	20	20	--	--
Z-Baffles (Option ZZ)	--	--	4-5	--	4-5	--	--	--

* Replacement parts for obsolete unit heaters are limited. Cabinet parts are not available. ** Not available for Model UA.

REFERENCES:

Replacement Parts and Service Forms,
Form RZ-NA

P-PILOTS, Pilots

P-STATS, Thermostats and Accessories

P-GC, Gas Conversion

P-LTR-TUBES, Burner Rack Carryover and
Lighter Tubes

P-RG/RP/RBL, Parts for Model Series RG and
RP

P-FAN-LIMIT, Fan and Limit Controls

***P-VALVES, Serial Nos., Gas Valves,
Ignition Controllers, and Maxitrol Gas
Controls

P-VENTER, Power Venter for Model Series X
and XE

737, Parts for Model PAK

CP-X-CONV, Convert Model Series X and RX
with G19 or T32 to G770

CP-RPV-CONV, Convert Model Series RPV
with G29 to G770

CP-RPV-PS, Pressure Switch Kit for Model
Series RPV

CP-X/SC-IGN, Convert Model Series X and RX
with G60 to G770

CP-EEDU/RPV/XLB-IGN, Convert Model Series
RPV with G60 to G770

Installation/Operation Forms for currently
manufactured Models, Form RZ-NA

I-OUTDOOR-DUCT, Models RX and RPV

I-XE/RGB/RPB, Model XE

I-X, Model X

Code	Description	125	150	175	200	225	250	300	350	400	
45A	Lift Eye	11026(2)	11026(2)	11026(2)	11026(2)	11026(2)	11026(2)	11026(2)	11026(2)	11026(2)	
45B	Hanger Angle	31904(2)	31904(2)	31904(2)	11012(2)	11012(2)	11012(2)	11012(2)	11012(2)	11012(2)	
46	Casing Top Assembly (includes insulation)	43936	43939	43939	43942	43942	43945	43945	43948	43951	
47	Top Front and Back	64667(2)	64669(2)	64669(2)	9810(2)	9810(2)	9771(2)	9771(2)	9735(2)	9542(2)	
48	Right Rear Heater Leg	10310	10310	10310	10312	10312	10312	10312	10312	10312	
49	Right Casing Side Panel	30145	30145	30145	14114	14114	14114	14114	14114	14114	
50	Left Rear Corner Leg - Control Side	68426	68426	68426	68428	68428	68428	68428	68428	68428	
51	Left Front Corner Leg - Control Side	68425	68425	68425	68427	68427	68427	68427	68427	68427	
52	Right Front corner Leg	10309	10309	10309	10311	10311	10311	10311	10311	10311	
53	Bottom Front & Rear Panel	Series 3	9889(2)	9850(2)	9850(2)	9810(2)	9810(2)	9771(2)	9771(2)	9735(2)	9542(2)
		RPV and CRPV 5, 6 and 8	64662(2)	64664(2)	64664(2)	9810(2)	9810(2)	9771(2)	9771(2)	9735(2)	9542(2)
54	Venter Shroud Assembly	43920	43920	43920	43921	43921	43921	43921	43921	43921	
55	Exhaust Grill	41992	41992	41992	41992	41992	41992	41992	41992	41992	
56	Access Panel	43954	43954	43954	43954	43954	43954	43954	43954	43954	
57	Bottom Left Side Panel	1/2" Gas Pipe	123999	123999	123999	123999	123999	123999	123999	123999	
		3/4" Gas Pipe	--	--	--	--	--	--	43429	43429	43429
57A	Gas Pipe Vinyl Grommet	1/2" Gas Pipe	102607	102607	102607	102607	102607	102607	102607	102607	
		3/4" Gas Pipe	--	--	--	--	--	--	15021	15021	15021
58	Reznor Name Plate	P/N 121264 (replaces 9538)									
59A	Lighter Cole Cover	RPV & CRPV 5, 6 & 8	10756(2)	10756(2)	10756(2)	10756(2)	10756(2)	10756(2)	10756(2)	10756(2)	
59B	Sight Hole cover	RPV & CRPV 5, 6 & 8	88688(2)	88688(2)	88688(2)	88688(2)	88688(2)	88688(2)	88688(2)	88688(2)	
60	Heater Bottom Pan	Aluminized	43432	43433	43433	43434	43434	43435	43435	43436	43437
		409 Stainless	48111	48112	48112	48113	48113	48114	48114	48115	48116
61	Flue Collection Box Assembly	RPV, HRPV prior to Series 8	43535	43536	43536	43537	43537	43538	43538	43539	43540
		RPV, HRPV Series 8	88353	88357	88357	136748	136748	88359	88359	92798	88348
		CRPV, HCRPV - All (no Series 8)	43535	43536	43536	43537	43537	43538	43538	43539	43540
62	Flue Duct Gasket	31900	31900	31900	31900	31900	31900	31900	31900	31900	
63	Side Gasket Strip	62933(2)	62933(2)	62933(2)	62933(2)	62933(2)	62933(2)	62933(2)	62933(2)	62933(2)	
64	Front and Rear Gasket Strips	62922(2)	62922(2)	62924(2)	62926(2)	62926(2)	62928(2)	62928(2)	62928(2)	62928(2)	
65	Flue Duct Assembly	41991	41991	41991	41991	41991	41991	41991	41991	41991	
66	Cover Plate Gasket	41996	41996	41996	41996	41996	41996	41996	41996	41996	
67	Flue Duct Cover Plate	41995	41995	41995	41995	41995	41995	41995	41995	41995	
68	Venter Gasket	44695	44695	44695	44695	44695	44695	44695	44695	44695	
69	Venter Restrictor	Models RPV, HRPV	43254	43255	43256	43257	43258	43259	43260	43261	
		Models CRPV, HCRPV	88506	--	68382	--	--	68386	88507	88507	88508
70	Venter Housing	RPV & CRPV 3 & 5	67716	67716	67716	67716	67716	67716	67716	67717	
		RPV 6 & 8 and CRPV 6	92778	92778	92778	92778	92778	92778	92778	92778	92792
71	Flow Switch Series 3 & 5 only - Do not order for units with Serial No. Date Code after ALJ (October 1986)	43847	43847	43847	43847	43847	43847	43847	43847	43847	
72	Wire Assembly	RPV & CRPV 6 & 8	93034	93034	93034	93034	93034	93034	93034	93034	
73	Pressure Switch (for RPV Series 3 and 5; see Code 80)	RPV & CRPV 6 & 8	125133 (replaces 68266) - see page 21, Code 304 before selecting								
		for High Altitude (above 4000 ft)	125134 (replaces 113234) - see page 21, Code 304 before selecting								
74	Compression Elbow	RPV 6 & 8 and CRPV 6	18224	18224	18224	18224	18224	18224	18224	18224	
75	Sensing Tube	RPV 6 & 8 and CRPV 6	133117 (replaces 92777)								
76	Aluminum Tubing, 1/4 x 18"	RPV 6 & 8 and CRPV 6	10349	10349	10349	10349	10349	10349	10349	10349	
77	Venter Wheel		43425	43425	43425	43425	43425	43425	43425	43814	
78*	Venter Motor Mounting Plate		131445	131445	131445	131445	131445	131445	131445	131448	
79*	Venter Motor (all motors include capacitor, P/N 103181)	(units mfgd beginning 7/94) 115V	131410	131410	131410	131410	131410	131410	131410	131410	
		(units mfgd beginning 7/94) 208V	131415	131415	131415	131415	131415	131415	131415	131415	
		(units mfgd beginning 7/94) 230V	131415	131415	131415	131415	131415	131415	131415	131415	
		(units mfgd beginning 3/94) 460V	125673	125673	125673	125673	125673	125673	125673	125673	
80	Pressure Switch Kit (sea level to 4000 ft) for RPV 3 & 5 (illustrated on page 6)	93033	93033	93033	93033	93033	93033	93033	93033	93033	
81	Vertical Vent Kit, Same as Option CC3	45021	45021	45021	45021	45021	45021	45021	45021	45021	

* Codes 78 and 79, replacement venter motor and venter motor mounting plate, apply to units manufactured after the dates shown in the table below. For units manufactured prior to the dates listed, replacing a venter motor must be done with a venter motor replacement kit that includes new motor mounting plates.

Venter Motor Replacement Kits

Voltage	P/N	Applies to Heaters Manufactured
115V	132377	prior to 7/94 (Serial No. Code ATG)
208V	132378	prior to 7/94 (Serial No. Code ATG)
230V	132378	prior to 7/94 (Serial No. Code ATG)
460V	132379	prior to 3/94 (Serial No. Code ATC)
575V	132377	prior to 7/94 (Serial No. Code ATG)

Parts for RPV Models prior to Series 3 and Series 5 prior to 1976 are not available except for replacement venters. For replacement venter motors for these older models, it is necessary to order one of the below listed venters. To install, remove the venter blower housing and discard.

for RPV 50-175

115V, P/N **29992** (Model LV301 venter)

208V, P/N **30229** (Model LV301B venter)

230V, P/N **30231** (Model LV301H venter)

Venter Sail Switch for above, P/N **7299** (2-wire)

for RPV 200-400

115V, P/N **29994** (Model LV401 venter)

208V, P/N **30233** (Model LV401B venter)

230V, P/N **30235** (Model LV401H venter)

Venter Sail Switch for above, P/N **13925** (2-wire)