



FX-05 & FX-06 CONTROLLERS ARE N/A SOME RETROFITS ARE AVAILABLE



IMPORTANT

1. Always include complete heater model and serial number so that any specification change can be considered for parts replacement. It can save time and expense.
2. In keeping with our policy of continuous product improvement, we reserve the right to alter any information shown here. Specifications are subject to change without notice.
3. We reserve the right to substitute functional replacements
4. Order by P/N; not Heater Option Designation.

Replacement Parts

Applies to: Indoor Model PDH, Model SDH, Model PEH, Model PXH, and Model SHH; and Outdoor Model RDH, Model REH, Model RXH, and Model RHH

Indoor Models



SDH
Gas-Fired Heat, Separated Combustion



PDH
Gas-Fired Heat, Power Vent



PEH
Electric Heat



PXH
Air Handler



SHH
Gas-Fired Heat, High Efficiency, Separated Combustion

Outdoor Models



RDH, Gas-Fired Heat, Power-Vented (with outside air hood attached)



REH
Electric Heat



RXH
Air Handler (with hood)









RHH Gas-Fired Heat, High-Efficiency, Power Vented (outside air hood attached)


Index

<p>A</p> <p>Air Proving Switch 3</p> <p>Amplifiers 11</p> <p>AquaSaver Timed Controls 44</p> <p>B</p> <p>Ball Joint 29</p> <p>Ball Valve 5</p> <p>Ball Valve Actuator 5</p> <p>Bearings 21</p> <p>Belts 21</p> <p>Bleed Line Hose 44</p> <p>Blowers 20</p> <p>Burner Assembly 20</p> <p>Burner End Shield 19</p> <p>Burner Shield 19</p> <p>C</p> <p>Cabinet Doors 36</p> <p>Cabinet Parts - Cooling Coil Module 24</p> <p>Cabinet Parts - Indoor High-Efficiency Model SHH 42</p> <p>Cabinet Parts - Indoor Model PDH 38</p> <p>Cabinet Parts - Indoor Model PEH 40</p> <p>Cabinet Parts - Indoor Model SDH 39</p> <p>Cabinet Parts - Mixing Box 30</p> <p>Cabinet Parts - Outdoor High-Efficiency Model RHH 42</p> <p>Cabinet Parts - Outdoor Model RDH 37</p> <p>Cabinet Parts - Outdoor Model REH 41</p> <p>Cabinet Parts for Option ECC Evaporative Cooling Module 43</p> <p>Capacitor 16, 27</p> <p>Reheat Compressor 27</p> <p>Contactors 7, 13</p> <p>Convenience Outlet 9</p> <p>Crankcase Heater 27</p> <p>Curb Adapter 35</p> <p>D</p> <p>Mixing Box Damper Controls 29</p> <p>Damper Arm 29</p> <p>Damper Assy (Option AR8) 28</p> <p>Damper Rod 29</p> <p>Dampers 29, 30</p> <p>Dehumidist, Option CL47 12</p> <p>Digital Controller FX05 for Opt DG 6</p> <p>Dirty Filter Switch 3</p> <p>Discharge Air Sensor 6</p> <p>Discharge Plenum 32</p> <p>Distribution Block 7</p> <p>Door 30, 32</p> <p>Door Latch 30, 32, 36</p> <p>Door Switch 9</p> <p>Downturn Plenum 32</p> <p>Drain Cover 19</p> <p>Drain Fitting 19</p> <p>Drain Gasket 19</p> <p>Condensate Drain Freeze-Resistant Trap 19</p> <p>Drive Components 21</p> <p>DSI (Direct Spark Ignition) Control Board 3</p> <p>Duct Flange 28, 32</p> <p>Ductstat 5, 10</p> <p>Ductstat Stage Adder 10</p> <p>E</p> <p>Economizer Logic Module 29, 30</p> <p>Electrical Component Locations 3</p> <p>Electric Heating Element 7</p> <p>Electric Heating Element Limit Control 7</p> <p>Electric Heat Section Electrical Compartment 6, 7</p> <p>Electrode 20</p> <p>Electronic Filter 6</p> <p>Enthalpy Sensor 29</p> <p>Evaporative Cooling Media Pads 43</p> <p>Evaporative Cooling Module 43</p>	<p>F</p> <p>Feed Line 44</p> <p>Fill and Drain Kits 45</p> <p>Electronic Filter 5</p> <p>Filter Drier 27</p> <p>Filters 28</p> <p>Firestat 10</p> <p>Flame Sensor 20</p> <p>Float Switch 44</p> <p>Float Valve 44</p> <p>Flue Collection Box 19</p> <p>Freeze Protection Controls 45</p> <p>Freezestat 5</p> <p>Froststat 26, 27</p> <p>Fuse 3, 7</p> <p>G</p> <p>Gas Conversion Kits 20</p> <p>Gas Pressure Switch 5</p> <p>Gas Valve (See Form P-VALVES) 5</p> <p>H</p> <p>Heat Exchanger 18, 19</p> <p>High Ambient Limit Control 10</p> <p>Hinge 36</p> <p>Inlet Air Hood (Option AS2) 28</p> <p>Horizontal Vent/ Combustion Air Terminal Kit (Same as Option CC6) 18</p> <p>Rubber Hose 44</p> <p>I</p> <p>ID Plug 4</p> <p>Inlet Screen 28</p> <p>L</p> <p>Label 36</p> <p>High Temperature Auto Reset Limit 3</p> <p>Reverse Flow Limit Switch 9</p> <p>Louvers 32, 33</p> <p>M</p> <p>Manifold Arrangement -- 8:1 Turndown 5</p> <p>Media 43</p> <p>Microprocessor Timer 44</p> <p>Modulating Gas Valve 5</p> <p>Damper Motor 29</p> <p>Discharge Damper Motor 32</p> <p>Motor Base 20</p> <p>Blower Motors 13, 16</p> <p>N</p> <p>Nozzles 32, 33</p> <p>O</p> <p>Gas Orifice 20</p> <p>Orifice Adapter Bushing 20</p> <p>Outside Air Relative Humidity Transmitter, Option DT5 12</p> <p>Overloads 13</p> <p>P</p> <p>Paint 36</p> <p>Phase Loss Control 3</p> <p>Plug-in Cards 6</p> <p>Potentiometer 29</p> <p>Pre-Filters (Option PF4 and PF5) 43</p> <p>Combustion Air Pressure Switch 3, 4</p> <p>Pulleys 21</p> <p>Pump 44</p> <p>Pump and Float Control 44</p> <p>Pump Support 44</p> <p>R</p> <p>Rating Plate 2</p> <p>DX Cooling Cabinet with Reheat 27</p> <p>Relay 3, 4, 7, 45</p> <p>Time Delay Relay 5</p> <p>Remote Console 12</p> <p>Remote User Interface 12</p>	<p>Primary Air Restrictor 20</p> <p>Return Air Controller 29</p> <p>Reverse Flow Limit Switch 9</p> <p>Roof Curb 34, 35, 36</p> <p>Room Command Module 12</p> <p>S</p> <p>Intake Screen 44</p> <p>SCR Power Controller 7</p> <p>Sensing Tube Assembly 21</p> <p>Sensor 10, 11</p> <p>Sensor Mixing Tube Holder 6</p> <p>Serial No. 2</p> <p>Service Switch 9</p> <p>Damper Motor Connecting Shaft 29</p> <p>Shaft (Blower) 21</p> <p>Signal Conditioner 5</p> <p>Smoke Detector 10</p> <p>2-Way Solenoid Valve 45</p> <p>3-Way Solenoid Valve 45</p> <p>Spring Isolation 20</p> <p>Sprinkler Pipe 44</p> <p>Starters 13</p> <p>Step Controller 7</p> <p>Disconnect Switch 13</p> <p>Pressure Null Switch 29</p> <p>Pressure Switch (refrigerant) 27</p> <p>2-position Switch 10</p> <p>T</p> <p>Static Pressure Tap 16</p> <p>Temperature Controller 45</p> <p>Terminal Block 44</p> <p>Terminal Board for Thermostat 3</p> <p>Thermostatic Expansion Valve for Reheat Circuit 27</p> <p>Thermostats 12</p> <p>Time Delay Relay 5, 6</p> <p>Transducer 5</p> <p>Transformer 3, 4, 7, 16, 44</p> <p>U</p> <p>Ultra-Violet, Germicidal Light 27</p> <p>V</p> <p>Ball Valve 44</p> <p>Variable Frequency Drive 3, 4</p> <p>Vent/Combustion Air Kits - SDH & SHH 17</p> <p>Vent Cap 17</p> <p>Venter Block Assembly 17, 42</p> <p>Venter Components 16, 17</p> <p>Venter Housing 16, 17</p> <p>Venter Motor 16, 17</p> <p>Venter Motor and Wheel Assembly 16, 17</p> <p>Venter Motor Capacitor 16</p> <p>Venter Speed Controller 6</p> <p>Vertical Vent - Model RDH 17</p> <p>Vertical Vent/Combustion Air Terminal Kit (Same as Option CC2) 17, 18</p> <p>W</p> <p>Water Hammer Arrestor 44</p> <p>Wheel 16, 17</p>
---	---	---

Space-Mounted Thermostats and Controls

<p>CODE 80 - 1-stage, 50-90° F, 24V, Honeywell T812C1000 Heating/Cooling Thermostat, P/N 255350 (Same as Option CL1)</p>		<p>CODE 81 - Electronic Two-Stage non-programmable Thermostat, M/H TH5220D1159, 40-90°F, 24V, 2-stage heating/2-stage cooling, P/N 220630 (Same as Option CL22)</p>	
<p>CODE 82 - Electronic Two-Stage, 7-day Programmable Thermostat, Touch screen, M/H TB8220U1003, 2-stg heating/2-stg cooling, P/N 257338 (Same as Option CL23)</p>		<p>CODE 83 - 5-2 Programmable Thermostat, 45-88°F, M/H TH411D1007, 24 volt, heating/cooling, P/N 220632 (Same as Option CL52)</p>	
<p>CODE 84 - Electronic 7-day Programmable, 2-stage heating/2-stage cooling, 24v, switching subbase with auto/cool/off/heat switch and auto/on fan switch, Honeywell #T7350D1008, P/N 221038 (Same as Option CL33)</p>		<p>CODE 85 - Locking Thermostat Cover P/N 257464, Height 6-1/2" (165mm), Width 7-1/2" (191mm), Depth 2-15/16" (75mm) - fits thermostats in CODES 80-83 (Same as Option CM1) P/N 257463, Height 7-1/4" (184mm), Width 9-3/4" (248mm), Depth 3-3/8" (86mm) - fits thermostat CODES 80-84 (Same as Opt CM1B)</p>	
<p>CODE 86 - Room Command Module Sensing Space Temperature, P/N 211423, part of Digital Control Options DG1 and DG2</p>		<p>CODE 87 - Room Command Module Sensing Discharge Temperature, P/N 211424, part of Digital Control Options DG5 and DG6</p>	
<p>CODE 89 - Wall-mounted Space Temperature Sensor, Option CL67, used with D12 B, C, D, E, F, G -- Part is no longer available; order replacement P/N 260599. This is not a direct replacement; contact your factory representative or the factory Service Department for wiring instructions.</p>		<p>CODE 90 - Optional Remote User Interface, P/N 223125, same as Option RB2A for use w/ Digital Control Options D12 B, C, D, E, F, G</p>	
<p>CODE 91 - Outside Air Relative Humidity Transmitter, P/N 206081 (included with all D12 control options)</p>		<p>CODE 92 - Wall-Mounted Dehumidistat, P/N 177231, same as Option CL47 (used with cooling coil with reheat Option AU7)</p>	

Remote Consoles



Optional RC style remote console includes a mounting ring so that the console may be either recessed or wall mounted. The box is of 16 gauge steel with knockout holes for field wiring. The cover is made of plastic with custom engraving. Order replacement parts for Option RC remote console by part number.

CODE	Description	P/N
100	Console Box - 10-1/16 x 6-5/8 x 2-5/8	107010
	Console Box - 15-1/16 x 6-5/8 x 2-5/8	107011
101	Mounting Ring for 10-1/16" lg box	107014
	Mounting Ring for 15-1/16" lg box	107015
102	Red Light, Solico 3039-3-11-41610	101889
103	SPDT Switch, Cutler Hammer #7505K6, 15 amps	101901
104	DPDT Switch, Cutler Hammer #7561K6, 15 amps	101900
81 (pg 11)	1-Stage Heating Thermostat	255350
84 (pg 11)	1 or 2-Stage Heating/Cooling Thermostat	220630
234 (pg 28)	Potentiometer	16110

Console Option Dimensions			
(approximate dimensions with mounting ring*)			
Console Options	Length	Height	Depth
All RC 1, 2, 3, 4, 5, 6, 9	10-3/4"	7-5/8"	2-5/8"
RC 7, 8, 10, 12 without an optional control on the console	10-3/4"	7-5/8"	2-5/8"
RC 7, 8, 10, 12 with an optional control on the console	15-3/4"	7-5/8"	2-5/8"
All RC 11	15-3/4"	7-5/8"	2-5/8"

* Subtract 5/8" from L & H when recessing console (not using wall-mounting ring)